



INSTALLATION INSTRUCTIONS MAGAZINE FLOORPLATE CAR GLASS BREAKER

1. Remove the magazine floorplate/base according to the manufacturer's instructions.

2. During the installation of the DPM magazine floor-plate/base also place the internal factory magazine safety plate that is placed in the magazine between the magazine spring and original magazine base.

ATTENTION: For some magazine models a different floorplate safety plate (Pic.1) is included in the package in order to fit and lock the DPM floorplate to that specific magazine.

WARNINGS: Always read and follow the operating and safety instructions for use of the accessory. Always wear safety goggles to protect your eyes, gloves to protect your hands and wear other appropriate safety items for protection. It is suggested to use the glass breaking floorplate with the magazine removed from the firearm. Grasp magazine in hand securely and use as such. Do not use excessive force while using product. Always maintain a firm footing and control of the tool. After use, always inspect the tool and discard immediately if damage is suspected. Only use this product as that which it was designed. Modification or alteration of this product will void all warranties and may reduce its safety and function. Breaking non safety glass may result in large shards of remaining glass and potential for serious personal injury or death. We suggest to not use on non safety glass. Failure to follow the warnings and instructions may result in serious injury or death. Use only the correct model magazine floorplate with correct model pistol, substitutions is not allowed. If you decide to use with magazine still installed in the pistol then please follow our other warnings.

Always use the DPM magazine floorplate **WITHOUT** ammunition loaded in the chamber of the firearm. During usage always point the pistol in a safe direction. Never use this product with your finger on the trigger, engage any and all pistol safeties if available. DPM Systems Technologies, its affiliates, distributors or resellers are not responsible for damage or injuries sustained during the proper or improper use of this product.

INSTRUCTIONS FOR GLOCK 9mm, 40 S&W

ATTENTION: For 9mm Magazine Use ALWAYS the Factory Black Safety Plate. For Glock 40 S&W Caliber Magazine Exchange the black color Factory Safety Plate with DPM Red Safety Plate that is inguded.



SUGGESTED RAMMING AREAS



DPM magazine glass breaker installation video
<https://youtu.be/aoPs5uYfksq>

Copyright ©2017 DPM Systems Technologies Ltd