



Reactive Target System LTD.



Static Target

USER MANUAL




www.fab-defense.com

43, Yakov Olamy St. Mishmar Hashiva, ISRAEL 50297


Tel: +972 3 960 3399 | Fax: +972 3 960 3312

Parts List (Fig 1)

1. Target Base
2. Rectangular Pole
3. Self-Healing Torso Target



Step 1. Insert the Rectangular Pole (2) into the Target Base (1) as shown in Fig. 2.



Step 2. Place the Torso Target (3) on the Rectangular Pole (2) as shown in Fig. 3.

