

BALDR RL

Thank you for purchasing this Olight Product. Please read this manual carefully before use and keep it for future reference!




DANGER

- DO NOT throw the light directly into human eyes. This may cause temporary blindness, or permanent damage to the eyes.
- DO NOT cover the light head when the light is on, or place the light head on the ground. The radiation energy of the light may cause damage to the light itself, or even result in burning to other materials.
- DO NOT leave the light in any type of fabric bag or fusible plastic container under high temperature.


WARNING

- Keep out of reach of children.
- After being on for a long time, the surface of the light may reach 50°C or higher. In this case, DO NOT touch the light to prevent bur.

IN THE BOX



SPECIFICATIONS





Max. Output: 5mw
Max Runtime: 75h
Wavelength: 640-660nm
HIGH: 14,400cd
LOW: 3,600cd
HIGH: 240m
LOW: 120m

* The laser level is Class 3R, obeying the standard IEC60825-1 requirement.

* Results are given based on tests using two 3V 1600mAh CR123A batteries. The tests obey ANSI/NEMA FL1 standard.



* 1120 lumens is the output brightness while battery level is full. When battery power is lowering (less than 30%), the maximum output brightness is limited in 500 lumens.

PRODUCT OVERVIEW



BEFORE FIRST USE

Please open the tailcap as shown in the picture. Remove the insulating film and close the tailcap.



BATTERY INSTALLATION

1. Pull up on the spring lock and open the tailcap. Place the batteries inside the body following the direction of the positive and negative marks.

CONTENTS

- (EN) English _ _ _ _ _ 01
- (FI) Finnish _ _ _ _ _ 01
- (NO) Norwegian _ _ _ _ _ 02
- (SV) Swedish _ _ _ _ _ 03
- (NED) Nederland _ _ _ _ _ 04
- (PL) Polska _ _ _ _ _ 05
- (DE) Deutsch _ _ _ _ _ 06
- (RU) Русский _ _ _ _ _ 07
- (ES) Español _ _ _ _ _ 08
- (UA) Ukrainian _ _ _ _ _ 09
- (JP) 日本語 _ _ _ _ _ 10
- (TH) ไทย _ _ _ _ _ 11
- (FR) Français _ _ _ _ _ 12
- (BG) български _ _ _ _ _ 13
- (IT) Italia _ _ _ _ _ 14
- (SK) Slovenský jazyk _ _ _ 15

(EN) English

OPERATION

THREE LIGHT SETTINGS AVAILABLE: You can choose between LED light Only, Laser only, and LIGHT&LASER combined by flipping a rotating switch underneath the light. Brightness level changes and strobe mode are only available while using LED light only and LIGHT&LASER combined mode.

CONSTANT ON/OFF: Single click either side switch for constant on. When the light is on, click either side switch again to turn it off.

MOMENTARY ON: When the light is off, press and hold either side switch. Let go of the switch and it will turn off.

CHANGE THE BRIGHTNESS LEVEL: When the light is on, quickly double click (or click three times or more) either side switch to change the brightness level. When the light is turned on again, it will return to the previously used brightness level.

STROBE: Press both sides of the switch and release to enter strobe mode. Click either side switch to turn it off.

(FI) Finnish


KÄYTÖSSÄ KOLME VALOASETUSTA: Voit

01


LIGHT INSTALLATION

Open the swing arm as shown below. Make sure that the rail insert used fits inside the rail notch without any movement. Close the swing arm once it is aligned.

Pull open the swing arm



Close the swing arm



SUPPORTED BATTERY

• 2 x CR123A

valita halutun valoasetuksen kääntämällä valon alapuolella sijaitsevaa pyöriivää kytkintä seuraavasti: LED- valo, laser tai LED-/laser-yhdistelmä.

JATKUVASTI PÄÄLLÄ/POIS: Kumman tahansa sivun katkaisijan painallus kytkee valon jatkuvasti päälle. Kun valo on päällä, kumman tahansa sivun katkaisijan painallus kytkee valon pois päältä.

HETKELLISESTI PÄÄLLÄ: Valon ollessa pois päältä, paina ja pidä molemmat sivukytkimet painettuina. Valo sammuu, kun ete kytkestä irrotetaan.

MUUTA KIRKKAUSTASO: Valon ollessa päällä, vaihda kirkkaustaso kaksoisnapsauttamalla nopeasti (tai napsauttamalla kolme kertaa tai useammin) toista sivukytkintä. Kun valo kytkeytyy uudelleen päälle, se palaa aikaisemmin käytettyyn kirkkaustasoon.

VILKKUVA: Paina kytkimen kumpaakin puolta ja vapauta ete siirtyäksesi vilkkuvaan tilaan. Poistu tilasta napsauttamalla toista sivukytkintä.

(NO) Norwegian